

# Positive Application of ASTM Guidance for the Occurrence and Mobility of NAPL in Sediment

Sediment Management Working Group Sponsor Forum

November 14, 2024



Emma Applegate  
Dan Canavan, PG  
Jeffrey Hale, PG

# Site and Sediment Characteristics

## Site Setting

- Active oil refinery
- Tidally influenced creek
- Stream reshaped & dredged over time
- Highly modified shoreline
- Flow largely comprised of non-contact cooling water


## Sediments

- Strata: weathered red shale, peat, and silt
- Target interval: non-plastic silt  $\leq 15$  feet
- EPH concentrations  $\leq 170,000$  mg/kg
- Initial NAPL saturation 0.21% to 35.89%
- NAPL conductivity 0.0 to  $1.4 \times 10^{-8}$  cm/s



# Site and Sediment Characteristics

Total EPH in Sediment



# Site and Sediment Characteristics

← 1 Mile →

Discrete Sediment Sample  
EPH Concentration

Compare & Contrast

'B'  
Tributary

'A'  
Primary  
Stream

10x vertical exaggeration

● >100,000 mg/kg   
 ● >30,000 mg/kg   
 ● >20,000 mg/kg   
 ● >10,000 mg/kg   
 ● >1,000 mg/kg   
 ● <1,000 mg/kg



# ASTM Standard Guides for NAPL Mobility and Migration in Sediment

- E3268-21 – Sample Collection, Field Screening, and Sample Handling
- E3281-21a – Screening Process to Categorize Samples for Laboratory NAPL Mobility Testing
- E3282-22 – Evaluation Metrics




# ASTM Standard Guides for NAPL Mobility and Migration in Sediment

- Systematic process to evaluate NAPL presence & mobility in sediment
- Procedures include:
  - Sediment sample collection
  - Sample processing
  - Visual observation
  - LIF screening
  - UV/white light photography
  - Mobility testing
  - Mobility weight of evidence approach




# NAPL Mobility and Migration in Sediments – Evaluation Metrics (ASTM E3282-22)



- **Tier 1 – Field Testing for NAPL Presence**
  - Screen with LIF or visual inspection
  - Confirm with shake test method or UV photography or hydrophobic dye test
  - End Point #1 if no NAPL identified
- **Tier 2 – Pore Scale Lab Mobility Evaluation**
  - Evaluate NAPL mobility in pores interior to NAPL body
  - Can choose centrifuge or water drive
  - If mobile by centrifuge proceed to water drive
  - End Point # 2 if NAPL immobile at pore scale
- **Tier 3 – NAPL Body Scale Migration Evaluation**
  - NAPL body expansion / migration
  - End Point #3 if NAPL body is immobile



# NAPL Mobility and Migration in Sediments – Evaluation Metrics (Modified Approach)





- **Tier 1 – Field Testing for NAPL Presence**
  - Evaluate multiple lines of evidence sequentially
  - Exclude shake test due to bias
    - Commonly produces sheen in absence of other indicators
    - Liberates molecules that coalesce to form sheen/film
  - Replace with other indicators (e.g., PID, EPH)
  - UV fluorescence photography strong differentiator
  - End Point #1 if no visual nor UV evidence of NAPL
- **Tier 2 – Pore Scale Lab Mobility Evaluation**
  - Apply centrifuge first (most likely to liberate NAPL)
  - Apply water drive if NAPL liberated by centrifuge (more representative of field conditions)



# Tier 1 – Field Testing for NAPL Presence

## LIF Measurements



- High data density and spatial coverage
- Indirect indicator with less 'stand-alone' certainty
- Should be supported by other lines of evidence
- Subject to interferences
- Beware of exaggerated amplitude scale (%RE)

# Tier 1 – Field Testing for NAPL Presence

## LIF Measurements

← 1 Mile →

Laser Induced Fluorescence Probes

10x vertical exaggeration



>120% RE




<120% RE

Observations of “No Visual Evidence of NAPL” exclusively <120% RE intervals

# Tier 1 – Field Testing for NAPL Presence

## Visual Observation




### Definitions / Categories

- **No visual evidence** – no sheen or NAPL is observed
- **Sheen** – sheen present; NAPL not observed
- **Blebs** – droplets of NAPL; matrix not visually contaminated or saturated (typically immobile)
- **Coated** – sediment grains coated with NAPL; unsaturated pores
- **Saturated** – pores saturated with NAPL; may freely drain



# Tier 1 – Field Testing for NAPL Presence


## Visual Observation








# Tier 1 – Field Testing for NAPL Presence

## Visual Observation




- Difficult to discern NAPL from black silt
- Difficult to discern pore saturation in fine-grained sediments with potential oil-particle aggregates
- “No visual evidence” easily discernible in some sediments
- Visible NAPL saturation in sample with 23.7% initial NAPL saturation by Dean-Stark method

# Tier 1 – Field Testing for NAPL Presence other LOE and UV




EPH concentration superimposed: <3.0 to 170,000 mg/kg





# Tier 2 – Pore Scale Lab Mobility Testing Weight of Evidence NAPL Mobility Evaluation




- Centrifugal force 25X gravity for ten hours
- Site-specific temperatures due to cooling water discharge / potential reduced viscosity
- Pre-centrifuge (initial) NAPL and water saturation (Dean-Stark)
- Post-centrifuge NAPL and water saturation (Dean-Stark)
- Description of fluid extruded from the sample
- NAPL effective conductivity



# Tier 2 – Pore Scale Lab Mobility Testing

## Weight of Evidence NAPL Mobility Evaluation

- $K_n$  = effective conductivity of NAPL (cm/sec)
- $Q_n$  = average NAPL flow rate from sample during centrifuge (cm<sup>3</sup>/sec)
- $A$  = area of discharge from test sample (orthogonal to the flow) (cm<sup>2</sup>)
- $i$  = hydraulic gradient imposed during test (dimensionless)



# Tier 2 – Pore Scale Lab Mobility Testing

## Weight of Evidence NAPL Mobility Evaluation

Lines of Evidence Used In NAPL Mobility Scoring				Weight of Evidence	
Initial NAPL Saturation	NAPL Saturation Reduction After Centrifuge (25g - 10 hours)	NAPL Expressed During Centrifuge (25g - 10 hours)	NAPL Effective Conductivity	NAPL Mobility Score Sum	Interpretation
> 30% = +1	≥ 10% = +1	NAPL Expressed = 0	≥10 <sup>-7</sup> cm/s = +1	≥ 0 = mobile	
10 - 30% = 0	< 10% = -1	Not Expressed = -1	<10 <sup>-7</sup> cm/s = -1	< 0 = immobile	
< 10% = -1					

# Tier 2 – Pore Scale Lab Mobility Testing

## Weight of Evidence NAPL Mobility Evaluation

Sediment Sample Information		Lines of Evidence Used In NAPL Mobility Scoring				Weight of Evidence	
		Initial NAPL Saturation	NAPL Saturation Reduction After Centrifuge (25g - 10 hours)	NAPL Expressed During Centrifuge (25g - 10 hours)	NAPL Effective Conductivity	NAPL Mobility Score Sum	Interpretation
Sample ID	Depth (ft-bss)	> 30% = +1	≥ 10% = +1	NAPL Expressed = 0	≥10 <sup>-7</sup> cm/s = +1	≥ 0 = mobile	
		10 - 30% = 0	< 10% = -1	Not Expressed = -1	<10 <sup>-7</sup> cm/s = -1	< 0 = immobile	
		< 10% = -1					
SED-H1	1.65-1.75	-1	-1	-1	-1	-4	Immobile
SED-H2	0.35-0.45	-1	-1	0	-1	-3	Immobile
SED-H3	0.55-0.65	-1	-1	0	-1	-3	Immobile
SED-H3	1.25-1.35	1	-1	0	-1	-1	Immobile
SED-H4	1.35-1.45	-1	-1	0	-1	-3	Immobile
SED-H5	0.05-0.15	-1	-1	-1	-1	-4	Immobile
SED-H5	3.1-3.2	-1	-1	-1	-1	-4	Immobile
SED-H7	2.8-2.9	0	-1	-1	-1	-3	Immobile
SED-H7	3.3-3.4	0	-1	-1	-1	-3	Immobile
SED-H8	1.7-1.8	0	-1	0	-1	-2	Immobile
SED-H8	2.8-2.9	0	-1	0	-1	-2	Immobile
SED-H9	0.3-0.4	0	-1	0	-1	-2	Immobile
SED-H9	0.4-0.5	-1	-1	0	-1	-3	Immobile
SED-H10	0.05-0.15	0	-1	0	-1	-2	Immobile
SED-H11	1.2-1.3	-1	-1	0	-1	-3	Immobile
SED-H11	1.65-1.75	-1	-1	0	-1	-3	Immobile
SED-H11	2.0-2.1	0	-1	0	-1	-2	Immobile
SED-H13	1.25-1.35	-1	-1	-1	-1	-4	Immobile
SED-H13	3.15-3.25	0	-1	-1	-1	-3	Immobile
SED-H15	1.1-1.2	0	-1	0	-1	-2	Immobile
SED-H16	0.7-0.8	-1	-1	0	-1	-3	Immobile
SED-H16	0.15-0.25	-1	-1	-1	-1	-4	Immobile
SED-H16	1.4-1.5	0	-1	0	-1	-2	Immobile
SED-H17	0.7-0.8	-1	-1	-1	-1	-4	Immobile
SED-H17	4.5-4.6	-1	-1	-1	-1	-4	Immobile

Sediment Sample Information		Lines of Evidence Used In NAPL Mobility Scoring				Weight of Evidence	
		Initial NAPL Saturation	NAPL Saturation Reduction After Centrifuge (25g - 10 hours)	NAPL Expressed During Centrifuge (25g - 10 hours)	NAPL Effective Conductivity	NAPL Mobility Score Sum	Interpretation
Sample ID	Depth (ft-bss)	> 30% = +1	≥ 10% = +1	NAPL Expressed = 0	≥10 <sup>-7</sup> cm/s = +1	≥ 0 = mobile	
		10 - 30% = 0	< 10% = -1	Not Expressed = -1	<10 <sup>-7</sup> cm/s = -1	< 0 = immobile	
		< 10% = -1					
SED-H18	1.8-1.9	0	-1	0	-1	-2	Immobile
SED-H18	2.55-2.65	-1	-1	0	-1	-3	Immobile
SED-B132	1.6-1.7	-1	-1	0	-1	-3	Immobile
SED-B133	2.5-2.6	0	-1	0	-1	-2	Immobile
SED-B136	1.7-1.8	-1	-1	-1	-1	-4	Immobile
SED-B136	8.7-8.8	-1	-1	0	-1	-3	Immobile
SED-B136	9.1-9.2	-1	-1	-1	-1	-4	Immobile
SED-B138	8.0-8.1	-1	-1	-1	-1	-4	Immobile
SED-B139	6.2-6.3	-1	-1	0	-1	-3	Immobile
SED-B141	0.0-0.1	-1	-1	-1	-1	-4	Immobile
SED-B141	1.0-1.1	-1	-1	-1	-1	-4	Immobile
SED-B141	5.0-5.1	-1	-1	-1	-1	-4	Immobile
SED-B141	6.0-6.1	-1	-1	0	-1	-3	Immobile
SED-B141	8.4-8.5	-1	1	0	-1	-1	Immobile
SED-B141	11.0-11.1	-1	1	0	-1	-1	Immobile
SED-B142	0.0-0.1	-1	-1	0	-1	-3	Immobile
SED-B142	1.0-1.1	-1	-1	-1	-1	-4	Immobile
SED-B142	2.15-2.25	-1	-1	-1	-1	-4	Immobile
SED-B142	5.3-5.4	-1	1	0	-1	-1	Immobile
SED-B143	8.1-8.2	-1	-1	0	-1	-3	Immobile
SED-O2	14.5 - 14.6	0	-1	0	-1	-2	Immobile
SED-O2	16.4-16.5	-1	-1	0	-1	-3	Immobile
SED-O3	15.1-15.2	-1	-1	0	-1	-3	Immobile

- 48 Samples Tested
- 25 Locations

# Tier 2 – Pore Scale Lab Mobility Testing

## Weight of Evidence NAPL Mobility Evaluation

Sediment Sample Information		Lines of Evidence Used In NAPL Mobility Scoring				Weight of Evidence	
		Initial NAPL Saturation	NAPL Saturation Reduction After Centrifuge (25g - 10 hours)	NAPL Expressed During Centrifuge (25g - 10 hours)	NAPL Effective Conductivity	NAPL Mobility Score Sum	Interpretation
Sample ID	Depth (ft-bss)	> 30% = +1 10 - 30% = 0 < 10% = -1	≥ 10% = +1 < 10% = -1	NAPL Expressed = 0 Not Expressed = -1	≥ 10 <sup>-7</sup> cm/s = +1 < 10 <sup>-7</sup> cm/s = -1	≥ 0 = mobile < 0 = immobile	
SED-H1	1.65-1.75	-1	-1	-1	-1	-4	Immobile
SED-H2	0.35-0.45	-1	-1	0	-1	-3	Immobile
SED-H3	0.55-0.65	-1	-1	0	-1	-3	Immobile
SED-H3	1.25-1.35	1	-1	0	-1	-1	Immobile
SED-H4	1.35-1.45	-1	-1	0	-1	-3	Immobile
SED-H5	0.05-0.15	-1	-1	-1	-1	-4	Immobile
SED-H5	3.1-3.2	-1	-1	-1	-1	-4	Immobile
SED-H7	2.8-2.9	0	-1	-1	-1	-3	Immobile
SED-H7	3.3-3.4	0	-1	-1	-1	-3	Immobile
SED-H8	1.7-1.8	0	-1	0	-1	-2	Immobile
SED-H8	2.8-2.9	0	-1	0	-1	-2	Immobile
SED-H9	0.3-0.4	0	-1	0	-1	-2	Immobile
SED-H9	0.4-0.5	-1	-1	0	-1	-3	Immobile
SED-H10	0.05-0.15	0	-1	0	-1	-2	Immobile
SED-H11	1.2-1.3	-1	-1	0	-1	-3	Immobile
SED-H11	1.65-1.75	-1	-1	0	-1	-3	Immobile
SED-H11	2.0-2.1	0	-1	0	-1	-2	Immobile
SED-H13	1.25-1.35	-1	-1	-1	-1	-4	Immobile
SED-H13	3.15-3.25	0	-1	-1	-1	-3	Immobile
SED-H15	1.1-1.2	0	-1	0	-1	-2	Immobile
SED-H16	0.7-0.8	-1	-1	0	-1	-3	Immobile
SED-H16	0.15-0.25	-1	-1	-1	-1	-4	Immobile
SED-H16	1.4-1.5	0	-1	0	-1	-2	Immobile
SED-H17	0.7-0.8	-1	-1	-1	-1	-4	Immobile
SED-H17	4.5-4.6	-1	-1	-1	-1	-4	Immobile


Initial  
NAPL  
Sat

23.7%  
(visual)

14.0%



10.4%


13.5%





# Tier 2 – Pore Scale Lab Mobility Testing Weight of Evidence NAPL Mobility Evaluation





- **Tier 1 – Field Testing for NAPL Presence**
  - Some relatively elevated LIF responses sufficient to be NAPL
  - Limited visual observation of NAPL; partly attributable to nature of sediment (black, fine-grained)
  - Instances of elevated EPH ( $\leq 170,000$  mg/kg)
  - Strong UV response in some cores; absent in others (consistent with other lines of evidence)
- **Tier 2 – Pore Scale Lab Mobility Evaluation**
  - Immobile at pore scale based on weight of evidence from centrifuge testing
  - Endpoint #2 achieved

- ASTM methods provide a useful framework and uniform terminology for identifying NAPL in sediments and evaluating its mobility
- Improved by modifying sequence of testing and replacing shake test with other lines of evidence (e.g., chemical analysis)
- NAPL may be difficult to visually discern in fine-grained, black sediments, especially as oil-particle aggregates
- LIF provides indirect assessment with high data density of lesser certainty
- UV light photography is very useful for identifying NAPL in sediments; corroborated by EPH concentrations
- Site-specific, pore-scale NAPL immobility demonstrated in fine-grained sediments by weight of evidence

# Thank You!

Emma Applegate [eapplegate@kleinfelder.com](mailto:eapplegate@kleinfelder.com)

Dan Canavan, PG [dcanavan@kleinfelder.com](mailto:dcanavan@kleinfelder.com)

Jeffrey Hale, PG [jehale@kleinfelder.com](mailto:jehale@kleinfelder.com)

